

Gestión de medios Audiovisuales


Manual y uso de GVE

- ▶ Servicio de Apoyo Técnico a la Docencia. EVLT
 - ▶ Juan Francisco Fernández Domínguez jffernandez@uma.es
 - ▶ Juan Miguel Jiménez Fernández jmjimenezf@uma.es

Aula Tipo 0



Aula Tipo 1



Aula tipo 2




▶ Grabación
de clases



▶ Aforo > 80


Aula Tipo 3



▶ Aforo > 80

Grabación
Streaming






GlobalViewer Enterprise									
SCHEDULING SCHEDULING SCHEDULING SCHEDULING SCHEDULING									
Room Name	Controller Type	Device Name	Device	Power	Device	Lighting	WPA		
BluePho7211	MS-C 220 DP	Optima7211	Optima7211	ON	ON	ON	ON		
BlackAC101	IPX 250	Black EDP-10100	Black EDP-10100	ON	ON	ON	ON		
BlackAC102	IPX 250	Black EDP-10100	Black EDP-10100	ON	ON	ON	ON		
BlackAC103	IPX 250	Optima7211	Optima7211	ON	ON	ON	ON		
BlackAC103-1	MS-C 220 DP	Sharp PG-040	Sharp PG-040	ON	ON	ON	ON		



Conectividad

Botoneras



MLC-104 IP PLUS



MLC Plus 100

Panel Tipo 3





GestionAV

<http://gestionav.evlt.uma.es>


Usuario: DNI

Clave inicial: conserjeria1x

Funcionalidades

- ▶ Encendido y apagado de los medios del aula
- ▶ Control del estado del aula
- ▶ Gestión del cañón
- ▶ Conocer uso en tiempo real
- ▶ Alertas
- ▶ Estadísticas de uso

Helpdesk



The screenshot displays the GlobalViewer Enterprise 2.6.1 interface. The top navigation bar includes tabs for HELP DESK, SCHEDULING, MONITORING, REPORTING, SYSTEM MENU, and USER PREFERENCES. The main content area features a table with columns for room status, room name, button status, lock status, device name, projector status, overall state, and lamp hours. The table lists various rooms, including A4-Aula1 through A4-Aula8, ARQ-Aula 2 through ARQ-Aula 4, and their respective devices like Epson BrightLink 575Wi and Sony VPL-EX226. The interface also includes a search bar for rooms and a GVE Location Tree on the left side.

OFF	ON	Aula	Botonera	Bloqueo	Dispositivo	Proyector	Estado	Horas Lampara
		A4-Aula1			Epson BrightLink 575Wi			
		A4-Aula2			NEC UM330W			
		A4-Aula3			NEC M311W			
		A4-Aula4			NEC M311W			
		A4-Aula5			NEC M311W			
		A4-Aula6			NEC M311W			
		A4-Aula7			NEC M311W			
		A4-Aula8			NEC M311W			
		ARQ-Aula 2			Sony VPL-EX226			
		ARQ-Aula 3			Sony VPL-EX226			
		ARQ-Aula 4			Sony VPL-EX226			

- ▶ Selección de aula
- ▶ Conocer estado
- ▶ Seleccionar equipos para gestionar
- ▶ Encendido y apagado
- ▶ Bloqueo del aula


Helpdesk

OFF ON	Aula ▲	Botonera	Bloqueo 🔒 🔒	Dispositivo	Proyector	Estado	Horas Lampara
	A4-Aula1			Epson BrightLink 575Wi		✓	
	A4-Aula2			NEC UM330W		✓	
	A4-Aula3			NEC M311W		✓	
	A4-Aula4			NEC M311W		✓	
	A4-Aula5			NEC M311W		✓	
	A4-Aula6			NEC M311W		✓	

Helpdesk





- ▶ Bloqueo/Desbloqueo de todo el aula
- ▶ Encendido/Apagado de todo el aula




Helpdesk

► Gestión botonera



Helpdesk

► Gestión Proyector



Helpdesk

► Gestión Pantalla



Scheduling

GlobalViewer Enterprise 2.2.1

Logged in as: jmjin [Log out]

HELP DESK | SCHEDULING | MONITORING | SYSTEM MENU | USER PREFERENCES


Manage Schedules | Calendar | Schedule Log

Filter By: -- Select Filter -- -- Select Sub Filter -- Reset

Name ▲	Recurrence Type	(StartDate, EndDate)	LastExeDate	Active	Edit	Delete
Apagado general	Daily	(29/09/2015,N/A)	11/11/2015	☐		
Prueba 1	Daily	(23/11/2015,N/A)	24/11/2015	☒		
prueba 2	Run Once	(23/11/2015,N/A)	24/11/2015	☒		

- ▶ Gestión de eventos
- ▶ Apagado general
- ▶ Encendido automático

Monitoring



GlobalViewer Enterprise 2.2.1

Logged in as: j...@...
Monitors

HELP DESK | SCHEDULING | **MONITORING** | SYSTEM MENU | USER PREFERENCES

Manage Monitors | Event Alert List Log

Filter By: -- Select Filter -- -- Select Sub Filter -- Reset

Monitor	Condition	Active	Edit	Delete
Lamp hours	Display Lamp Hours > 3500	☒		

- ▶ Programación de alertas
- ▶ Aviso de sustitución de lámparas
- ▶ Botoneras sin conexión

Reporting

The image shows a screenshot of the GlobalViewer Enterprise 2.2.1 web application interface. At the top, there is a dark blue header with the text 'GlobalViewer Enterprise 2.2.1' in white. Below the header is a navigation bar with several menu items: 'HELP DESK', 'SCHEDULING', 'MONITORING', 'REPORTING' (which is highlighted in blue), 'SYSTEM MENU', and 'USER PREFERENCES'. Below the navigation bar, there is a section titled '+ Create Report' with a green plus icon. This section contains a table with four columns: 'Name', 'Type', 'Created By', and 'Date Range'. The table lists several reports, including 'Assets Report', 'Controller Status Report', 'Energy Usage Forecast Report', 'Energy Usage Report', 'Filter Forecast Report', 'Input Source Usage Report', 'Lamp Forecast Report', and 'Prueba'. Each row provides details about the report's name, type, who created it, and the date range for which it is generated.

Name ▲	Type	Created By	Date Range
Assets Report	Inventory	System	Today
Controller Status Report	Usage	System	5 Days
Energy Usage Forecast Report	Forecast	System	5 Days
Energy Usage Report	Usage	System	5 Days
Filter Forecast Report	Forecast	System	Today
Input Source Usage Report	Usage	System	5 Days
Lamp Forecast Report	Forecast	System	Today
Prueba	Custom	msg	5 Days

- Generación de informes y reportes

User preferences

GlobalViewer Enterprise 2.2.1

HELP DESK | SCHEDULING | MONITORING | SYSTEM MENU | **USER PREFERENCES**

User Settings | Request Access

Personal Settings

User Name: jmjimenez

First Name: Juan Miguel

Last Name: Jimenez Fernandez

Email: jmjimenezf@uma.es

SMS:

Phone:

Mobile:

Help Desk View: Conserjeria

Update

Change Your Password

Password:

New Password:

Confirm New Password:

Change Password Cancel

- ▶ Opciones de usuario
- ▶ Cambio de claves
- ▶ Selección de vista

Dudas y Preguntas

Ayuda

evlt.uma.es [Soporte Sicaú](#)

[Solicitar ayuda espacios docentes](#)